


Quick Start Guide

Rugged tablet KT-KP12 Series



Disclaimer

Thank you for purchasing our products, please read this manual carefully before you use it.

If the product fails during use, please contact our after-sales staff in time.

The product is upgraded according to the customized version. Product upgrades may result in some of the functions of the product does not match the manual, please prevail in kind, or contact our customer service staff.

If you do not follow the instructions in the manual to operate, and therefore any loss caused by the user shall be borne by the user.

The final interpretation of this book belongs to our company.

Attention:


1. The installation and maintenance of this product by professionals, please do not disassemble and maintenance and other operations.
2. Product scanning module is a type II beam, please do not look directly at it.
3. Avoid using in the strong light source direct light and light source is not stable place, so as not to affect the service life of the photoreceptor.
4. In order to protect the safe use of equipment, please be sure to use the standard power adapter, away from sources of ignition.

Contents


1. Product Structure Schematic	- 1 -
2. SIM /TF Card Installation Method	- 2 -
3. Battery Charging	- 2 -
4. Basic Function	- 2 -
4.1 Barcode scanning	- 2 -
4.2 Wifi connection	- 2 -
4.3 Cellular connection	- 3 -
4.4 NFC function	- 3 -
5. Common Problems and Solutions	- 3 -

1. Product Structure Schematic


Front View



Back View



2. SIM /TF Card Installation Method



- 1) Insert the SIM card or TF memory card into the corresponding card tray as shown in the figure.
- 2) Card slot type: NANO SIM card + NANO SIM card or NANO SIM card + TF card

3. Battery Charging

- 1) Use a USB Tyep-C cable to charge: Use the Type-C cable and power adapter supplied with the device. Connect the device to a appropriate electrical outlet for charging. When charging the charging indicator is red, when the battery is fully charged, the indicator will turn green.
- 2) Use a cradle to charge: Place the device into the charging cradle, plug the Type-C cable into the cradle's Type-C interface and connect the power adapter for charging. (Charging cradle is optional)

4. Basic Function

4.1 Barcode scanning

You can scan barcode by using the barcode scanning program that comes with the device. Or you can develop scanning program by yourself. Press the left and right buttons to scan barcodes.

4.2 Wifi connection

Click "Setting" on the home screen to enter Network and Internet Settings, tap the Wi-Fi switch

to turn on. Choose a WLAN from the list and click to connect. If you choose an encrypted network, please enter password to connect.

Note: When both Wi-Fi and mobile data are turned on, system will prioritize connecting to WLAN. If WLAN is disconnected, system will automatically switches to mobile data.

4.3 Cellular connection

Please insert SIM card, the device will automatically register to the corresponding network. please turn on the mobile data switch in settings to enable data services.

Note: Please turn off data services in time to extend standby time and save data traffic when no need to use Internet.

4.4 NFC function

Please turn on the NFC function switch in the settings, then you can read card in NFC detection area. (NFC detection area is located on the back of the device)

5. Common Problems and Solutions

If an abnormality occurs while using the phone, refer to the following table for troubleshooting.

FQ	Causes	Solutions
Unable to connect to PC end	whether the Type-C cable connect well	Try re-plugging the cable
SIM card error	SIM card is damaged	Contact your network service provider
	SIM card not properly installed	Make sure the SIM card is installed
	Dirt on the metal side of the SIM card	Wipe the metal contacts of the

		SIM card with a clean cloth
Unable to connect to network	Invalid SIM card	Contact your network provider
	Out of network service area	Check the service area with your network provider
	Weak signal	Move to a strong signal area and try again
Unable to make calls	Call barring feature in use	Cancel call barring settings
	Fixed dialing feature used	Cancel fixed dialing settings
Unable to charge	Damaged battery or charger	Replace the battery or charger with a new one
	Poor contact	Check if the plug is connected